

BEFORE TAKEOFF

FLAPS.....GREEN LIGHT
STABILIZER TRIM.....UNITS

**FOR SINGLE ENGINE TAXI OUT
AFTER BOTH ENGINES ARE RUNNING**

GENERATORS.....ON
PROBE HEAT.....ON
ANTI ICE.....
APU.....
ENG START SWITCHES.....CONT
RECALL.....CHECKED
START LEVERS.....IDLE DETENT

AFTER TAKEOFF

ENGINE BLEEDS.....ON
ISOLATION.....AUTO
PACKS.....AUTO
LANDING GEAR.....UP and OFF
FLAPS.....UP, NO LIGHTS

DESCENT

PRESSURIZATION.....LAND ALT__ft
RECALL.....CHECKED
LDG DATA.....FLAP__VREF__MINS__
APP BRIEF.....COMPLETED

APPROACH

ALTIMETERS.....SET and X-CKD
RWY/A.BRAKE...../

LANDING

ENG START SWS.....CONT
ALTIMETERS...SET and X-CKD
SPEEDBRAKE.....ARMED
LANDING GEAR.....DOWN
FLAP.....GREEN LT

RWY CHG - REPEAT LAND CL

BEFORE TAKEOFF

FLAPS.....GREEN LIGHT
STABILIZER TRIM.....UNITS

**FOR SINGLE ENGINE TAXI OUT
AFTER BOTH ENGINES ARE RUNNING**

GENERATORS.....ON
PROBE HEAT.....ON
ANTI ICE.....
APU.....
ENG START SWITCHES.....CONT
RECALL.....CHECKED
START LEVERS.....IDLE DETENT

AFTER TAKEOFF

ENGINE BLEEDS.....ON
ISOLATION.....AUTO
PACKS.....AUTO
LANDING GEAR.....UP and OFF
FLAPS.....UP, NO LIGHTS

DESCENT

PRESSURIZATION.....LAND ALT__ft
RECALL.....CHECKED
LDG DATA.....FLAP__VREF__MINS__
APP BRIEF.....COMPLETED

APPROACH

ALTIMETERS.....SET and X-CKD
RWY/A.BRAKE...../

LANDING

ENG START SWS.....CONT
ALTIMETERS...SET and X-CKD
SPEEDBRAKE.....ARMED
LANDING GEAR.....DOWN
FLAP.....GREEN LT

RWY CHG - REPEAT LAND CL